
Defining Performance

Which airplane has the best performance?



Response Time and Throughput

- Response time
 - How long it takes to do a task
- Throughput
 - Total work done per unit time
 - e.g., tasks/transactions/... per hour
 - How are response time and throughput affected by
 - Replacing the processor with a faster version?
 - Adding more processors?
 - We'll focus on response time for now...

Relative Performance

- Define Performance = 1/Execution Time
- "X is n time faster than Y"

 $Performan \omega_{x} / Performan \omega_{y}$

= Execution time_Y / Execution time_X = n

Example: time taken to run a program

- 10s on A, 15s on B
- Execution Time_B / Execution Time_A = 15s / 10s = 1.5
- So A is 1.5 times faster than B


Measuring Execution Time

Elapsed time

- Total response time, including all aspects
 Processing, I/O, OS overhead, idle time
- Determines system performance
- CPU time
 - Time spent processing a given job
 - Discounts I/O time, other jobs' shares
 - Comprises user CPU time and system CPU time
 - Different programs are affected differently by CPU and system performance

CPU Clocking

Operation of digital hardware governed by a constant-rate clock



Clock period: duration of a clock cycle

e.g., 250ps = 0.25ns = 250×10⁻¹²s

Clock frequency (rate): cycles per second

• e.g., 4.0GHz = 4000MHz = 4.0×10⁹Hz

Chapter 1 — Computer Abstractions and Technology — 5

CPU Time

CPU Time = CPU Clock Cycles × Clock Cycle Time

CPUClock Cycles Clock Rate

Performance improved by

- Reducing number of clock cycles
- Increasing clock rate
- Hardware designer must often trade off clock rate against cycle count



CPU Time Example

- Computer A: 2GHz clock, 10s CPU time
- Designing Computer B
 - Aim for 6s CPU time
 - Can do faster clock, but causes 1.2 × clock cycles
- How fast must Computer B clock be?

$$Clock Rate_{B} = \frac{Clock Cycles_{B}}{CPU Time_{B}} = \frac{1.2 \times Clock Cycles_{A}}{6s}$$

$$Clock Cycles_{A} = CPU Time_{A} \times Clock Rate_{A}$$

$$= 10s \times 2GHz = 20 \times 10^{9}$$

$$Clock Rate_{B} = \frac{1.2 \times 20 \times 10^{9}}{6s} = \frac{24 \times 10^{9}}{6s} = 4GHz$$

Chapter 1 — Computer Abstractions and Technology — 7

Instruction Count and CPI

ClockCycles=InstructionCount×CyclesperInstruction

CPUTime=InstructionCount×CPI×ClockCycleTime

Instruction Count×CPI

ClockRate

- Instruction Count for a program
 - Determined by program, ISA and compiler
- Average cycles per instruction
 - Determined by CPU hardware
 - If different instructions have different CPI
 - Average CPI affected by instruction mix

CPI Example

- Computer A: Cycle Time = 250ps, CPI = 2.0
- Computer B: Cycle Time = 500ps, CPI = 1.2
- Same ISA
- Which is faster, and by how much?

```
CPUTime_{A} = Instruction Count \times CPI_{A} \times Cycle Time_{A}
= I \times 2.0 \times 250 ps = I \times 500 ps \quad A \text{ is faster...}
CPUTime_{B} = Instruction Count \times CPI_{B} \times Cycle Time_{B}
= I \times 1.2 \times 500 ps = I \times 600 ps
CPUTime_{A} = \frac{I \times 600 ps}{I \times 500 ps} = 1.2 \quad ... \text{ by this much}
```

CPI in More Detail

If different instruction classes take different numbers of cycles

$$Clock Cycles = \sum_{i=1}^{n} (CPI_i \times Instruction Count_i)$$

$$CPI = \frac{Clock Cycles}{Instruction Count} = \sum_{i=1}^{n} \left(CPI_i \times \frac{Instruction Count_i}{Instruction Count} \right)$$



CPI Example

 Alternative compiled code sequences using instructions in classes A, B, C


Class	А	В	С
CPI for class	1	2	3
IC in sequence 1	2	1	2
IC in sequence 2	4	1	1

- Sequence 1: IC = 5
 - Clock Cycles
 = 2×1 + 1×2 + 2×3
 = 10
 - Avg. CPI = 10/5 = 2.0

- Sequence 2: IC = 6
 - Clock Cycles
 = 4×1 + 1×2 + 1×3
 = 9
 - Avg. CPI = 9/6 = 1.5

Performance Summary


The BIG Picture




Performance depends on

- Algorithm: affects IC, possibly CPI
- Programming language: affects IC, CPI
- Compiler: affects IC, CPI
- Instruction set architecture: affects IC, CPI, T_c

Power Trends



In CMOS IC technology




SPEC CPU Benchmark

- Programs used to measure performance
 - Supposedly typical of actual workload
- Standard Performance Evaluation Corp (SPEC)
 - Develops benchmarks for CPU, I/O, Web, …

SPEC CPU2006

- Elapsed time to execute a selection of programs
 Negligible I/O, so focuses on CPU performance
- Normalize relative to reference machine
- Summarize as geometric mean of performance ratios
 - CINT2006 (integer) and CFP2006 (floating-point)



CINT2006 for Opteron X4 2356

Name	Description	IC×10 ⁹	CPI	Tc (ns)	Exec time	Ref time	SPECratio
perl	Interpreted string processing	2,118	0.75	0.40	637	9,777	15.3
bzip2	Block-sorting compression	2,389	0.85	0.40	817	9,650	11.8
gcc	GNU C Compiler	1,050	1.72	0.47	24	8,050	11.1
mcf	Combinatorial optimization	336	10.00	0.40	1,345	9,120	6.8
go	Go game (AI)	1,658	1.09	0.40	721	10,490	14.6
hmmer	Search gene sequence	2,783	0.80	0.40	890	9,330	10.5
sjeng	Chess game (AI)	2,176	0.96	0.48	37	12,100	14.5
libquantum	Quantum computer simulation	1,623	1.61	0.40	1,047	20,720	19.8
h264avc	Video compression	3,102	0.80	0.40	993	22,130	22.3
omnetpp	Discrete event simulation	587	2.94	0.40	690	6,250	9.1
astar	Games/path finding	1,082	1.79	0.40	773	7,020	9.1
xalancbmk	XML parsing	1,058	2.70	0.40	1,143	6,900	6.0
Geometric mean						11.7	

High cache miss rates



SPEC Power Benchmark

Power consumption of server at different workload levels

- Performance: ssj_ops/sec
- Power: Watts (Joules/sec)

$$Overall ssj_opsper Watt = \left(\sum_{i=0}^{10} ssj_ops \right) / \left(\sum_{i=0}^{10} power_i \right)$$



SPECpower_ssj2008 for X4

Target Load %	Performance (ssj_ops/sec)	Average Power (Watts)
100%	231,867	295
90%	211,282	286
80%	185,803	275
70%	163,427	265
60%	140,160	256
50%	118,324	246
40%	920,35	233
30%	70,500	222
20%	47,126	206
10%	23,066	180
0%	0	141
Overall sum	1,283,590	2,605
∑ssj_ops/ ∑power		493

Chapter 1 — Computer Abstractions and Technology — 17